8085 Instruction Set

Introduction

An instruction is the pattern which is used by microprocessor. In 8085 instruction is the combination of opcode and operand. Here opcode is the operation code and operand is the data. And instruction length could be one byte, two byte and three byte.

Instruction Set of 8085

- An instruction is a binary pattern designed inside a microprocessor to perform a specific function.
- The entire group of instructions that a microprocessor supports is called *Instruction Set*.
- 8085 has 246 instructions.
- Each instruction is represented by an 8-bit binary value.
- These 8-bits of binary value is called Op-Code or Instruction Byte.

Classification of Instruction Set

- Data Transfer Instruction
- Arithmetic Instructions
- Logical Instructions
- Branching Instructions
- Control Instructions

- These instructions move data between registers, or between memory and registers.
- These instructions copy data from source to destination.
- While copying, the contents of source are not modified.

Opcode	Operand	Description
MOV	Rd, Rs M, Rs Rd, M	Copy from source to destination.

- This instruction copies the contents of the source register into the destination register.
- The contents of the source register are not altered.
- If one of the operands is a memory location, its location is specified by the contents of the HL registers.
- Example: MOV B, C or MOV B, M

Opcode	Operand	Description
MVI	Rd, Data M, Data	Move immediate 8-bit

- The 8-bit data is stored in the destination register or memory.
- If the operand is a memory location, its location is specified by the contents of the H-L registers.
- Example: MVI B, 57H or MVI M, 57H

Opcode	Operand	Description
LDA	16-bit address	Load Accumulator

- The contents of a memory location, specified by a 16bit address in the operand, are copied to the accumulator.
- The contents of the source are not altered.
- Example: LDA 2034H

Opcode	Operand	Description
LDAX	B/D Register Pair	Load accumulator indirect

- The contents of the designated register pair point to a memory location.
- This instruction copies the contents of that memory location into the accumulator.
- The contents of either the register pair or the memory location are not altered.
- Example: LDAX B

Opcode	Operand	Description
LXI	Reg. pair, 16-bit data	Load register pair immediate

- This instruction loads 16-bit data in the register pair.
- Example: LXI H, 2034 H

Opcode	Operand	Description
LHLD	16-bit address	Load H-L registers direct

- This instruction copies the contents of memory location pointed out by 16-bit address into register L.
- It copies the contents of next memory location into register H.
- Example: LHLD 2040 H

Opcode	Operand	Description
STA	16-bit address	Store accumulator direct

- The contents of accumulator are copied into the memory location specified by the operand.
- Example: STA 2500 H

Opcode	Operand	Description
STAX	Reg. pair	Store accumulator indirect

- The contents of accumulator are copied into the memory location specified by the contents of the register pair.
- Example: STAX B

Opcode	Operand	Description
SHLD	16-bit address	Store H-L registers direct

- The contents of register L are stored into memory location specified by the 16-bit address.
- The contents of register H are stored into the next memory location.
- Example: SHLD 2550 H

Opcode	Operand	Description
XCHG	None	Exchange H-L with D-E

- The contents of register H are exchanged with the contents of register D.
- The contents of register L are exchanged with the contents of register E.
- Example: XCHG

Opcode	Operand	Description
SPHL	None	Copy H-L pair to the Stack Pointer (SP)

- This instruction loads the contents of H-L pair into SP.
- Example: SPHL

Opcode	Operand	Description
XTHL	None	Exchange H-L with top of stack

- The contents of L register are exchanged with the location pointed out by the contents of the SP.
- The contents of H register are exchanged with the next location (SP + 1).
- Example: XTHL

Opcode	Operand	Description
PCHL	None	Load program counter with H-L contents

- The contents of registers H and L are copied into the program counter (PC).
- The contents of H are placed as the high-order byte and the contents of L as the low-order byte.
- Example: PCHL

Opcode	Operand	Description
PUSH	Reg. pair	Push register pair onto stack

- The contents of register pair are copied onto stack.
- SP is decremented and the contents of high-order registers (B, D, H, A) are copied into stack.
- SP is again decremented and the contents of low-order registers (C, E, L, Flags) are copied into stack.
- Example: PUSH B

Opcode	Operand	Description
POP	Reg. pair	Pop stack to register pair

- The contents of top of stack are copied into register pair.
- The contents of location pointed out by SP are copied to the low-order register (C, E, L, Flags).
- SP is incremented and the contents of location are copied to the high-order register (B, D, H, A).
- Example: POP H

Opcode	Operand	Description
OUT	8-bit port address	Copy data from accumulator to a port with 8-bit address

- The contents of accumulator are copied into the I/O port.
- Example: OUT 78 H

Opcode	Operand	Description
IN	8-bit port address	Copy data to accumulator from a port with 8-bit address

- The contents of I/O port are copied into accumulator.
- Example: IN 8C H

Addition

- Any 8-bit number, or the contents of register, or the contents of memory location can be added to the contents of accumulator.
- The result (sum) is stored in the accumulator.
- No two other 8-bit registers can be added directly.
- Example: The contents of register B cannot be added directly to the contents of register C.

Subtraction

- Any 8-bit number, or the contents of register, or the contents of memory location can be subtracted from the contents of accumulator.
- The result is stored in the accumulator.
- Subtraction is performed in 2's complement form.
- If the result is negative, it is stored in 2's complement form.
- No two other 8-bit registers can be subtracted directly.

Increment / Decrement

- The 8-bit contents of a register or a memory location can be incremented or decremented by 1.
- The 16-bit contents of a register pair can be incremented or decremented by 1.
- Increment or decrement can be performed on any register or a memory location.

Opcode	Operand	Description
ADD	R M	Add register or memory to accumulator

- The contents of register or memory are added to the contents of accumulator.
- The result is stored in accumulator.
- If the operand is memory location, its address is specified by H-L pair.
- All flags are modified to reflect the result of the addition.
- Example: ADD B or ADD M

Opcode	Operand	Description
ADC	R	Add register or memory to accumulator with
	M	carry

- The contents of register or memory and Carry Flag (CY) are added to the contents of accumulator.
- The result is stored in accumulator.
- If the operand is memory location, its address is specified by H-L pair.
- All flags are modified to reflect the result of the addition.
- Example: ADC B or ADC M

Opcode	Operand	Description
ADI	8-bit data	Add immediate to accumulator

- The 8-bit data is added to the contents of accumulator.
- The result is stored in accumulator.
- All flags are modified to reflect the result of the addition.
- Example: ADI 45 H

Opcode	Operand	Description
ACI	8-bit data	Add immediate to accumulator with carry

- The 8-bit data and the Carry Flag (CY) are added to the contents of accumulator.
- The result is stored in accumulator.
- All flags are modified to reflect the result of the addition.
- Example: ACI 45 H

Opcode	Operand	Description
DAD	Reg. pair	Add register pair to H-L pair

- The 16-bit contents of the register pair are added to the contents of H-L pair.
- The result is stored in H-L pair.
- If the result is larger than 16 bits, then CY is set.
- No other flags are changed.
- Example: DAD B

Opcode	Operand	Description
SUB	R M	Subtract register or memory from accumulator

- The contents of the register or memory location are subtracted from the contents of the accumulator.
- The result is stored in accumulator.
- If the operand is memory location, its address is specified by H-L pair.
- All flags are modified to reflect the result of subtraction.
- Example: SUB B or SUB M

Opcode	Operand	Description
SBB	R M	Subtract register or memory from accumulator with borrow

- The contents of the register or memory location and Borrow Flag (i.e. CY) are subtracted from the contents of the accumulator.
- The result is stored in accumulator.
- If the operand is memory location, its address is specified by H-L pair.
- All flags are modified to reflect the result of subtraction.
- Example: SBB B or SBB M

Opcode	Operand	Description
SUI	8-bit data	Subtract immediate from accumulator

- The 8-bit data is subtracted from the contents of the accumulator.
- The result is stored in accumulator.
- All flags are modified to reflect the result of subtraction.
- Example: SUI 45 H

Opcode	Operand	Description
SBI	8-bit data	Subtract immediate from accumulator with borrow

- The 8-bit data and the Borrow Flag (i.e. CY) is subtracted from the contents of the accumulator.
- The result is stored in accumulator.
- All flags are modified to reflect the result of subtraction.
- Example: SBI 45 H

Opcode	Operand	Description
INR	R M	Increment register or memory by 1

- The contents of register or memory location are incremented by 1.
- The result is stored in the same place.
- If the operand is a memory location, its address is specified by the contents of H-L pair.
- Example: INR B or INR M

Opcode	Operand	Description
INX	R	Increment register pair by 1

- The contents of register pair are incremented by 1.
- The result is stored in the same place.
- Example: INX H

Opcode	Operand	Description
DCR	R M	Decrement register or memory by 1

- The contents of register or memory location are decremented by 1.
- The result is stored in the same place.
- If the operand is a memory location, its address is specified by the contents of H-L pair.
- Example: DCR B or DCR M

Opcode	Operand	Description
DCX	R	Decrement register pair by 1

- The contents of register pair are decremented by 1.
- The result is stored in the same place.
- Example: DCX H

Scope of research

Here we can developed new instruction format or instruction which is more easily understand by user and the microprocessor. and which has capability of fast execution speed with large data and less time.