



# **Analog Communication Systems**

## **EC-413-F**



# Lecture no 4,5,6



# **Topics to be covered**

**DSBSC, SSB & VSB**

# Double Side Band Suppressed Carrier (DSBSC)

- Power in a AM signal is given by  $\langle s^2(t) \rangle = \underbrace{\frac{1}{2} A_c^2}_{\text{Carrier Power}} + \underbrace{\frac{1}{2} A_c^2 \langle m^2(t) \rangle}_{\text{Sideband power}}$

- DSBSC is obtained by eliminating carrier component  
If  $m(t)$  is assumed to have a zero DC level, then

$$s(t) = A_c m(t) \cos \omega_c t$$

Spectrum →  $S(f) = \frac{A_c}{2} [M(f - f_c) + M(f + f_c)]$


Power →  $\langle s^2(t) \rangle = \frac{1}{2} A_c^2 \langle m^2(t) \rangle$

Modulation Efficiency →  $E = \frac{\langle m^2(t) \rangle}{\langle m^2(t) \rangle} \times 100 = 100\%$

## Disadvantages of DSBSC:


- Less information about the carrier will be delivered to the receiver.
- Needs a coherent carrier detector at receiver

# DSBSC Modulation




$$s(t) = A_c m(t) \cos \omega_c t$$

An Example of message energy spectral density.





Energy spectrum of the DSBSC modulated message signal.

# DSBSC Generation using Balanced Modulator



# DSBSC Generation using Ring








# DSBSC Demodulation

- Synchronous Detection
- Envelope Detection after suitable carrier reinsertion

# Carrier Recovery for DSBSC Demodulation


- Coherent reference for product detection of DSBSC can not be obtained by the use of ordinary PLL because there are no spectral line components at  $f_c$ .



(a) Costas Phase-Locked Loop

# Carrier Recovery for DSBSC Demodulation

- A squaring loop can also be used to obtain coherent reference carrier for product detection of DSBSC. A frequency divider is needed to bring the double carrier frequency to  $f_c$ .



(b) Squaring Loop

# Single Sideband (SSB) Modulation

➤ An **upper single sideband (USSB)** signal has a zero-valued spectrum for



$$|f| < f_c$$

➤ A **lower single sideband (LSSB)** signal has a zero-valued spectrum for

$$|f| > f_c$$

➤ **SSB-AM** – popular method ~ **BW** is *same* as that of the modulating signal.

Note: Normally SSB refers to SSB-AM type of signal



# Single Sideband Signal

► **Theorem** : A SSB signal has **Complex Envelope** and bandpass form as:

$$g(t) = A_c [m(t) \pm j\hat{m}(t)]$$

$$s(t) = A_c [m(t) \cos \omega_c t \mp \hat{m}(t) \sin \omega_c t]$$


Upper sign (-) → USSB

Lower sign (+) → LSSB

$\hat{m}(t)$  – **Hilbert transform** of  $m(t)$  →  $\hat{m}(t) \equiv m(t) * h(t)$  Where  $h(t) = \frac{1}{\pi t}$

$$H(f) = \mathfrak{F}[h(t)] \quad \text{and} \quad H(f) = \begin{cases} -j, & f > 0 \\ j, & f < 0 \end{cases}$$

Hilbert Transform corresponds to a  $-90^\circ$  phase shift



# Single Sideband Signal

**Proof:** Fourier transform of the complex envelope

$$G(f) = A_c \{M(f) \pm j\mathfrak{S}[\hat{m}(t)]\} = A_c \{M(f) \pm j\hat{M}(f)\}$$

Upper sign  $\rightarrow$  USSB  
Lower sign  $\rightarrow$  LSSB

Using  $\hat{m}(t) \equiv m(t) * h(t) \Rightarrow G(f) = A_c M(f) [1 \pm jH(f)]$

$$G(f) = \begin{cases} 2A_c M(f), & f > 0 \\ 0, & f < 0 \end{cases}$$

Recall 
$$V(f) = \frac{1}{2} \{G(f - f_c) + G^*[-(f + f_c)]\}$$

$$S(f) = A_c \begin{cases} M(f - f_c), & f > f_c \\ 0, & f < f_c \end{cases} + A_c \begin{cases} 0, & f > -f_c \\ M(f + f_c), & f < -f_c \end{cases}$$


Upper sign  $\rightarrow$  USSB

If **lower signs** were used  $\rightarrow$  **LSSB** signal would have been obtained

# Single Sideband Signal

$$G(f) = \begin{cases} 2A_c M(f), & f > 0 \\ 0, & f < 0 \end{cases}$$

$$S(f) = A_c \begin{cases} M(f - f_c), & f > f_c \\ 0, & f < f_c \\ 0, & f > -f_c \\ M(f + f_c), & f < -f_c \end{cases}$$



# SSB - Power

The normalized average power of the SSB signal

$$\langle s^2(t) \rangle = \frac{1}{2} \langle |g(t)|^2 \rangle = \frac{1}{2} A_c^2 \langle m^2(t) + [\hat{m}(t)]^2 \rangle$$

Hilbert transform does not change power.

$$\langle \hat{m}(t)^2 \rangle = \langle m^2(t) \rangle$$

SSB signal power is:

$$\langle s^2(t) \rangle = A_c^2 \langle m^2(t) \rangle$$

Power gain factor

Power of the modulating signal

The normalized peak envelope (PEP) power is:

$$\frac{1}{2} \max \langle |g(t)|^2 \rangle = \frac{1}{2} A_c^2 \langle m^2(t) + [\hat{m}(t)]^2 \rangle$$



# Generation of SSB

SSB signals have *both* **AM** and **PM**.

The **complex envelope** of SSB:

$$g(t) = A_c [m(t) \pm j\hat{m}(t)]$$

For the **AM** component,

$$R(t) = |g(t)| = A_c \sqrt{m^2(t) + [\hat{m}(t)]^2}$$

For the **PM** component,

$$\theta(t) = \angle g(t) = \tan^{-1} \left[ \frac{\pm \hat{m}(t)}{m(t)} \right]$$

## Advantages of SSB

- Superior detected signal-to-noise ratio compared to that of AM
- SSB has one-half the bandwidth of AM or DSB-SC signals

# Generation of SSB


SSB Can be generated using two techniques

1. Phasing method
2. Filter Method

Phasing method

$$g(t) = A_c [m(t) \pm j\hat{m}(t)]$$

This method is a special modulation type of IQ canonical form of Generalized transmitters discussed in Chapter 4 ( Fig 4.28)




(a) Phasing Method

# Generation of SSB


## Filter Method

The filtering method is a special case in which RF processing (with a sideband filter) is used to form the equivalent  $g(t)$ , instead of using baseband processing to generate  $g(m)$  directly. The filter method is the most popular method because excellent sideband suppression can be obtained when a crystal oscillator is used for the sideband filter. Crystal filters are relatively inexpensive when produced in quantity at standard IF frequencies.




(b) Filter Method


# Weaver's Method for Generating SSB.




# Generation of VSB




(a) Generation of VSB Signal




(b) Spectrum of DSB Signal



(c) Transfer Function of VSB Filter



(d) Spectrum of VSB Signal



(e) VSB Filter Constraint