Section-A

Semester: IIIrd Class:-EEE

Course Code: EE-201-F

Subject: - ELECTRONIC DEVICES & CIRCUITS

S. No.	Topic: - Introduction To The Syllabus, Review Of Energy Bands And Description Of The Material.	Time Allotted:-
1.	<b>Introduction</b> The syllabus comprises seven units. A major portion of the syllabus is related to the semiconductor materials and the semiconductor devices and two units are based upon the dielectric materials and magnetic materials. The conductors, insulator and semiconductors have different energy bands. Semiconductors are the materials which behave like insulator at absolute zero but their resistance decreases with the increase in temp and they behave like conductors at room temperature.	<u>10 min</u>
2	<ul> <li>Division of the Topic</li> <li>Introduction to the syllabus</li> <li>Discrete Energy levels in atomic structure</li> <li>Conduction and valence bands of insulator ,semi-conductor and conductor</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> The term conductor is applied to any material that will support a generous flow of Charge when a voltage source of limited magnitude is applied across its terminals. An insulator is a material that offers a very low level of conductivity when a voltage source is applied. A semi-conductor is a material that has a conductivity level somewhere between the extremes of the insulator and a conductor. For conductors resistivity ( $\rho$ )=10 <sup>-6</sup> $\Omega$ -cm For insulators $\rho$ =50 $\Omega$ -cm For semiconductors $\rho$ =10 <sup>-12</sup> $\Omega$ -cm	<u>5 min</u>
4	Question /Answer Q.What is 1 ev? Ans.1ev=1.6x 10 <sup>-19</sup> J Q.What is the energy gap between the valence band and the conduction band in the conductors? Ans. they are overlapped with each other.	<u>5 min</u>

#### Assignment to be given:- nil

- 2. Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 3. Electronic Devices And Ckt Theory: Boylested & Nashelsky; Pearson

### Lecture Plan -2

Semester:- IIIrd Class:-EEE Course Code: EE-201-F

Subject:-ELECTRONIC DEVICES & CIRCUITS Section-A

S. No.	Topic :-DRIFT VELOCITY ,MOBILITY, CONDUCTIVITY	Time Allotted:-
1.	<b>Introduction</b> The most important properties of the metals is their high electrical and thermal conductivity. Conductivity of the metals is associated with the presence of the free or 'conduction' electrons. These free electron move throughout the lattice and thus do not belong to a particular atom. Thus metal can be considered as a lattice of positive ion cores held together by means of a gas of electrons.	<u>10 min</u>
2	<ul> <li>Division of the Topic</li> <li>Ohm's law</li> <li>Conductivity of the material</li> <li>Illustration of the influence of collisions on the velocity of electrons</li> <li>Mobility</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> One important feature of ohm's law is the fact that current density remains constant in time as long as the E remains constant. Although this is not absolutely correct when we consider the problem of conduction from atomic point of view. From this we have concluded that the free electrons in the conductor must interact with the lattice of positive ions cores and hence they are not completely free.	<u>5 min</u>
4	Question /Answer Q. what is mobility? Ans. it is defined as the magnitude of average drift velocity per unit field. Q. what will be the effect of increase in temp on the resistivity of the conductors? Ans. resistivity increases with the increase in temp.	<u>5 min</u>

Assignment to be given:- derive the relationship between the drift velocity and the mobility.

Reference Readings:- 1Solid State Electronic Devices: Streetman & Banerjee; Pearson2Electronic Devices And Circuits: Milliman's & Halkins; MGHDoc. No.: DCE/0/15t Theory: Boylested & Nashelsky; PearsonRevision :00

#### Lecture Plan -3

Semester:-IIIrd Clas

Class:-EEE

Course Code:EE-201-F

#### Subject:-ELECTRONIC DEVICES & CIRCUITS Section-A

S. No.	Topic :-RELAXATION TIME ,COLISION TIME AND MEAN FREE PATH	Time Allotted:-
1.	<b>Introduction</b> When we consider the problem of conduction from atomic point of view. From this we have concluded that the free electrons in the conductor must interact with the lattice of positive ions cores and hence they are not completely free. The average time between collisions is called the collision time $T_c$ .	<u>10 min</u>
2	<ul> <li>Division of the Topic</li> <li>Relaxation time</li> <li>Collision time</li> <li>Relation between relaxation time and collision time</li> <li>Mean free path</li> <li>Mean free path in terms of collision time</li> </ul>	<u>30 min</u>
3.	Conclusion The mean free path of the electron is given by $\lambda = VT_c$ Here $\lambda =$ mean free path V=total velocity of an electron $T_c=$ average collision time	<u>5 min</u>
4	Question /Answer Q.what is the formula of mobility? Ans. $eT /m$ Q. how the relaxation time is related to the collision time? Ans. $T_c=T_c / (1-\langle \cos \Theta \rangle)$	<u>5 min</u>

Assignment to be given:-

- 2 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 3 Electronic Devices And Ckt Theory: Boylested & Nashelsky; Pearson

Semester:-IIIrd Class:-EEE Course Code:EE-201-F

Subject:-ELECTRONIC DEVICES & CIRCUITS Section-A

S. No.	Topic :-THERMAL CONDUCTIVITY AND WIEDEMANNFRANZ LAW	Time Allotted:-
1.	<b>Introduction</b> When a homogenous isotropic material is subjected to a temperature gradient, a flow of heat results in the direction opposite to that of the gradient in insulating solids the heat current is carried by lattice vibrations. This is also present in the conducting materials but the thermal conductivity due to the conduction electrons predominates in these materials.	<u>10 min</u>
2	<ul> <li>Division of the Topic</li> <li>Thermal conductivity of the metals</li> <li>Temperature gradient</li> <li>Specific heat of the electron gas at constant volume.</li> <li>Effect of temperature on the thermal conductivity.</li> <li>Wiedemann –franz law</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> There exists an interesting relationship between the electrical conductivity and the thermal conductivity of a metal. The theory predicts that $K/\sigma T$ for all metals should be equal to a universal constant. This law is known as wiedemann –franz law.	<u>5 min</u>
4	Question /Answer Q. what is the value of LORENZ number? Ans. 2.45x10 <sup>-8</sup> watt ohm degree <sup>2</sup> Q. wiedemann law is applicable for all temp conditions? Ans. it is not applicable at low temperature.	<u>5 min</u>

<u>Assignment to be given:-</u>derive the expression for the thermal conductivity and explain Wiedemann-franz law

- 2 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 3 Electronic Devices And Ckt Theory :Boylested & Nashelsky ; Pearson

Semester:-IIIrd Class:-EEE Course Code:EE-201-F

Subject:-ELECTRONIC DEVICES & CIRCUITS Section-A

S. No.	Topic : SUPERCONDUCTIVITY AND EFFECT OF MAGNETIC FIELD	Time Allotted:-
1.	<b>Introduction</b> Superconductivity was discovered in 1911 by Kamerlingh ones when he observed that the electrical resistivity of mercury disappeared completely at temperature below Approximately 4.2 degrees Kelvin. So a new term is introduced, transition temp. T <sub>c</sub> , at which the transition from normal state to the superconducting state occurs.	<u>10 min</u>
2	<ul> <li>Division of the Topic</li> <li>Introduction to the superconductivity.</li> <li>Transition temperature</li> <li>Reduction in transition temperature by the application of the magnetic field.</li> <li>Perfect diamagnetism</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> The transition temperature of a superconductor can be reduced by the application of the magnetic field. The transition from the superconducting to the normal state under influence of a magnetic field is reversible. The magnetic field which causes a superconductor to become normal is not necessarily an externally applied field; it may also arise as a result of electric current flow in the conductor. Thus superconductivity in a long circular wire of radius r may be destroyed when the current I exceeds the value Ic. This at the surface of the wire will produce the critical magnetic field Hc.	<u>5 min</u>
4	Question /Answer Q. what is the Silsbee's rule? Ans. Ic=2ПrHc Q. good conductors are not good superconductors. True or false? Ans.true	<u>5 min</u>

Assignment to be given:-

- 2 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 3 Electronic Devices And Ckt Theory: Boylested & Nashelsky; Pearson

# Lecture Plan -6

Semester:-IIIrdClass:-EEECourse Code:EE-201-F

 Subject:-ELECTRONIC DEVICES & CIRCUITS
 Section-B

S. No.	Topic :-REVIEW OF SI AND GE AS SEMICONDUCTOR MATERIALS, CONTINUITY EQUATION	Time Allotted:-
1.	<b>Introduction</b> The label semiconductor itself provides a hint as to its characteristics. The prefix semi itself applies to a range midway between two limits . the silicon and germanium are the semiconductor materials. They behave like insulator at absolute zero but their resistivity decreases with the increase in temp.	<u>10 min</u>
2	<ul> <li>Division of the Topic</li> <li>Semiconductor material</li> <li>Single crystal structure of silicon and germanium.</li> <li>Intrinsic semiconductor materials</li> <li>Extrinsic semiconductor materials</li> <li>Effect of temperature on the resistivity of the semiconductors.</li> <li>Continuity equation</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> An increase in the temperature of the semiconductor can result in a substantial increase in the no. of the free electrons in the material. Semiconductor materials such as Ge or Si show a reduction in resistance with the increase in temperature and therefore they are said to have a negative temperature coefficient.	<u>5 min</u>
4	Question /Answer Q. what are the majority carriers in the N-type semiconductor? Ans. Electrons. Q. what is the energy gap between the conduction band and the valence band in germanium? Ans. 0.67 ev	<u>5 min</u>

Assignment to be given:-

- 2 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 3 Electronic Devices And Ckt Theory: Boylested & Nashelsky; Pearson

# Lecture Plan -7

Semester:-IIIrd Class:-EEE Course Code:EE-201-F

#### Subject: ELECTRONIC DEVICES & CIRCUITS Section-B

S. No.	Topic :-P-N JUNCTION	Time Allotted:-
1.	Introduction	<u>10 min</u>
	The pn junction diode is formed by simply bringing these materials together using special techniques. At the instant the two materials are joined together the electrons and holes in the region of the junction will combine resulting in a lack of carriers in the region near the junction. This region of uncovered positive and negative ions is called the depletion region due to depletion of carriers in this region.	
2	<ul> <li>Division of the Topic</li> <li>&gt; p-n junction diode</li> <li>&gt;No bias</li> <li>&gt;forward bias</li> <li>&gt;reverse bias</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> In the absence of an applied bias voltage , the net flow of charge in any one direction for a semiconductor diode is zero. The current that exists under reverse bias conditions is called the reverse saturation current and it is represented by Is. A semiconductor diode is forward bias when the association p-type and positive & n-type and negative is established.	<u>5 min</u>
4	Question /Answer Q. in the reverse bias condition the reverse saturation current is due to which carriers? Ans. minority carriers Q. in the forward bias condition what happens to the depletion region? Ans. the width of depletion region decreases.	<u>5 min</u>

#### Assignment to be given:-

- 2 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 3 Electronic Devices And Ckt Theory :Boylested & Nashelsky ; Pearson

# Lecture Plan -8

Semester:-IIIrd Class:-EEE Course Code:EE-201-F

#### Subject:-ELECTRONIC DEVICES & CIRCUITS Section-B

S. No.	Topic :- DRIFT AND DIFFUSION	Time Allotted:-
1.	<b>Introduction</b> When external voltage is applied to p-n junction diode the movement of electrons & holes is known as diffusion. Flow of electrons & hole due to temp. gradient is known as diffusion	<u>10 min</u>
2	Division of the Topic	
	<ul> <li>Diffusion of carriers</li> <li>Drift of carriers</li> </ul>	
		<u>30 min</u>
3.	<b>Conclusion</b> Flow of carriers is due to concentration gradient is known as drift & due to temp. gradient is known as diffusion	<u>5 min</u>
4	Question /Answer Q. in the reverse bias condition the reverse saturation current is due to which carriers? Ans. minority carriers Q. in the forward bias condition what happens to the depletion region? Ans. the width of depletion region decreases.	<u>5 min</u>

Assignment to be given:-

- 4 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 5 Electronic Devices And Ckt Theory :Boylested & Nashelsky ; Pearson

#### Semester:-IIIrd Class:-EEE Course Code:EE-201-F

 Subject:-ELECTRONIC DEVICES & CIRCUITS
 Section-B

S. No.	<b>Topic :- DIFFUSION AND TRANSITION CAPACITANCE</b>	Time Allotted:-
1.	<b>Introduction</b> Electronic devices are sensitive to very high frequencies. Most shunt capacitive effects that can be ignored at lower frequencies because the reactance $Xc=1/2\pi$ fc is very large (open ckt equivalent). This however can't be ignored at very high frequencies .Xc will become sufficiently small due to the high value of f to introduce a shorting path.	<u>10 min</u>
2	<ul> <li>Division of the Topic</li> <li>Effect of frequency on the capacitive reactance</li> <li>Diffusion capacitance</li> <li>Transition capacitance</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> The capacitive effects are represented by a capacitor in parallel with the ideal diode. For the low and mid frequency applications the capacitor is not normally included in the diode symbol.	<u>5 min</u>
4	<ul> <li>Question /Answer</li> <li>Q. at low frequency the capacitive effects are negligible. TRUE or FALSE?</li> <li>Ans. At low frequency they are negligible because Xc is very large and equivalent to an open ckt.</li> <li>Q. in which biasing transition capacitance outweighs the diffusion capacitance?</li> <li>Ans. reverse bias region</li> </ul>	<u>5 min</u>

#### Assignment to be given:-

- 2 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 3 Electronic Devices And Ckt Theory: Boylested & Nashelsky; Pearson

# Lecture Plan -10

Semester:-IIIrd Class:-EEE

Course Code: EE-201-F

Subject:-ELECTRONIC DEVICES & CIRCUITS Section-B

S. No.	Topic :- BREAKDOWN MECHANISM IN P-N JUNCTION DIODE AND ZENER DIODE	Time Allotted:-
1.	Introduction	<u>10 min</u>
	In the reverse bias region, there is a point where the application of too negative voltage will result in a sharp change in the characteristics. The current increases at a very rapid rate in a direction opposite to that of the positive voltage region. The reverse bias potential that results in this dramatic change in the characteristics is called the Zener potential. and it is given by Vz.	
2	<ul> <li>Division of the Topic</li> <li>breakdown in reverse bias condition</li> <li>Avalanche breakdown</li> <li>Zener breakdown</li> <li>Zener diode</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> The zener region of the semiconductor diode should be avoided. The max reverse bias potential that can be applied to the diode before entering into the zener region is called the peak inverse voltage (referred to PIV) Or the peak reverse voltage referred to (PRV)	<u>5 min</u>
4	Question /Answer Q.what is the value of threshold voltage for the silicon? Ans.0.7V Q. what will be the effect of the increase in temp. on the reverse saturation current ? Ans. it becomes double for every 10 increase in temp.	<u>5 min</u>

#### Assignment to be given:-

- 2 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 3 Electronic Devices And Ckt Theory: Boylested & Nashelsky; Pearson

Semester:-IIIrd Class:-EEE Course Code:EE-201-F

 Subject:-ELECTRONIC DEVICES & CIRCUITS
 Section-B

S. No.	Topic :-LED,SOLAR CELL AND PHOTO DETECTORS	Time Allotted:-
1.	Introduction The increasing use of the digital display in calculators, watches, and all form of instrumentation has contributed to the current extensive interest in structures that will emit light when properly biased. Solar cells are very frequently used these days. They convert the solar energy into electrical energy The energy transmitted at discrete packages called photons and it is directly proportional to the frequency	<u>10 min</u>
2	<ul> <li>Division of the Topic</li> <li>Principle of LED</li> <li>Construction of LED</li> <li>Solar cell</li> <li>Photo diode</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> The two types in common use today to perform this function are the light emitting diode (LED) and the liquid crystal display. Photo diode detectors are used in the alarm system and in the counter operation. Solar cells are becoming very popular as an alternative source of energy but still some new developments are required to maximize the conversion efficiency of the solar cells. The series arrangement of solar cells permits a voltage beyond that of a single element.	<u>5 min</u>
4	Question /Answer Q.what is electroluminescence? Ans.the process of giving off light by applying an electrical source of energy. Q. what is efficacy? Ans. it is a measure of the ability of the device to produce a desired effect.	<u>5 min</u>

Assignment to be given:-

- 2 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 3 Electronic Devices And Ckt Theory: Boylested & Nashelsky; Pearson

#### Lecture Plan -12

Semester:-IIIrdClass:-EEECourse Code:EE-201-F

#### Subject:-ELECTRONIC DEVICES & CIRCUITS Section-B

S. No.	<b>Topic :- BRIEF INTRODUCTION TO THE PLANER TECHNOLOGY FOR DEVICE FABRICATION.</b>	Time Allotted:-
1.	Introduction	<u>10 min</u>
	The techniques applied to the manufacture of semiconductor devices are continually being reviewed, modified and upgraded. In recent years the primary emphasis has been in the yield rate, expanding the automation level and increasing the density level. The sequence of steps in the manufacturing of the discrete units has not changed that dramatically. However the manner in which step is performed has experienced a tremendous change.	
2	Division of the Topic	
	<ul> <li>Introduction to planer technology</li> <li>Basic steps in the planer technology</li> <li>Zone refining process</li> <li>Czochralski technique of ic fabrication.</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> Thus, the most important step in ic fabrication is to form the single crystal of germanium or the silicon. The polycrystalline material is first transformed into the molten state by RF induction coils. A single crystal "seed" of the desired impurity level is then immersed in the molten silicon and gradually withdrawn while the shaft holding the seed is slowly turning.	<u>5 min</u>
4	<ul> <li>Question /Answer</li> <li>Q. which methods are used for the transistor fabrication?</li> <li>Ans. There are three methods for the transistor fabrication: alloy junction Grown junction</li> <li>Diffusion</li> <li>Q. what is the function of the oxide layer in the transistor fabrication?</li> <li>Ans. It will reduce the surface leakage current.</li> </ul>	<u>5 min</u>

Assignment to be given:-

- 2 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 3 Electronic Devices And Ckt Theory: Boylested & Nashelsky; Pearson

Semester:-IIIrd Class:-EEE Course Code:EE-201-F

Subject:-ELECTRONIC DEVICES & CIRCUITS Section-B

S. No.	Topic :- OHMIC AND NON-OHMIC MATELS IN THE SEMICONDUCTOR JUNCTIONS	Time Allotted:-
1.	<b>Introduction</b> As the metals are good conductors of electricity. They allow the current to pass through them. The ohmic metals are those which follow the ohm's law and the non-ohmic resistances are those which don't follow the ohm's law according to which the current flowing in a conductor is directly proportional to the applied voltage provided the current conditions don't change.	<u>10 min</u>
2	<ul> <li>Division of the Topic</li> <li>Ohmic and non-ohmic metals</li> <li>Resistance of semiconductor junctions</li> <li>The characteristic cure of the semiconductor devices</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> the resistance of the semiconductor junction doesn't follow the ohm's law as most of the metals do. There is non-linear relationship between the current and the voltage.	<u>5 min</u>
4	<ul> <li>Question /Answer</li> <li>Q. what are the non-ohmic resistance?</li> <li>Ans. the materials which don't follow the ohm's law are called the non-ohmic resistance.</li> <li>Q. what is positive temperature coefficient?</li> <li>Ans. Metals have the positive temperature coefficient. The resistance increases with the increase temperature.</li> </ul>	<u>5 min</u>

Assignment to be given:-

- 2 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 3 Electronic Devices And Ckt Theory: Boylested & Nashelsky; Pearson

# Lecture Plan -14

Semester:-IIIrdClass:-EEECourse Code:EE-201-F

#### Subject:-ELECTRONIC DEVICES & CIRCUITS Section-C

S. No.	Topic :-Introduction ,working of BJT	Time Allotted:-
1.	Introduction	<u>10 min</u>
	UPTO 1947, the vacuum tubes were used in all the electronic devices. but after the discovery of transistor ,the advantages of this three terminal solid state device over the vacuum tubes were quite obvious, it was smaller, lightweight ,no heat requirements, less power absorption. Any many more.	
2	<ul> <li>Division of the Topic</li> <li>Introduction to transistor</li> <li>Transistor construction</li> <li>Transistor operation.</li> <li>Common base configuration</li> <li>Common emitter configuration</li> <li>Common collector configuration</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> For each transistor there is a region of operation on the characteristics which will ensure that the max. Ratings are not being exceeded and the output signal exhibits minimum distortion. These are defined by the manufacturer on the specification sheets. These specification sheets are the communication links between the user and the manufacturer. but it is important that the information provided must be recognized and correctly understood	<u>5 min</u>
4	Question /Answer Q. what is the biasing in the cut-off region in common base configuration? Ans. The collector –base and base- emitter junctions are both reverse biased. Q. what is the value of $V_{BE}$ In the saturation region? Ans. 0.7 V	<u>5 min</u>

Assignment to be given:-

- 2 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 3 Electronic Devices And Ckt Theory: Boylested & Nashelsky; Pearson

Semester:-IIIrd Class:-EEE Course Code:EE-201-F

 Subject:
 ELECTRONIC DEVICES & CIRCUITS
 Section-C

S. No.	Topic :-configuration & characteristics of BJT	Time Allotted:-
1.	<b>Introduction</b> Depending on which terminal is made common BJT is used in three configuration. CE,CB,CC	<u>10 min</u>
2	Division of the Topic Common base configuration	30 min
	<ul> <li>Common emitter configuration</li> <li>Common collector configuration</li> </ul>	<u>50 mm</u>
3.	<b>Conclusion</b> Transistor is used as an amplifier in CE configuration because of high current gain Transistor is used as voltage buffer in CC configuration because of unity voltage gain	<u>5 min</u>
4	<ul> <li>Question /Answer</li> <li>Q. Transistor is used as an amplifier in which region?</li> <li>Ans: active region</li> <li>Q. what is emitter follower?</li> <li>Ans. Transistor in CC configuration is known as emitter follower</li> </ul>	<u>5 min</u>

Assignment to be given:-

- 5 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 6 Electronic Devices And Ckt Theory: Boylested & Nashelsky; Pearson

# <u>Lecture Plan -16</u>

Semester:-IIIrdClass:-EEECourse Code:EE-201-F

#### Subject:-ELECTRONIC DEVICES & CIRCUITS Section-C

	Topic :- WORKING AND CHARACTRISTICS OF UJT	Time
S. No.		Allotted:-
1.	Introduction	<u>10 min</u>
	The UJT is a three terminal device. A slab of lightly doped n-type silicon material has two base contacts attaches to both ends of one surface and an aluminum rod alloyed to the opposite surface. The p-n junction of the device is formed at the boundary of the aluminum rod and the n-type silicon slab.	
2	<ul> <li>Division of the Topic</li> <li>Introduction to the UJT</li> <li>PEAK POINT</li> <li>VALLEY POINT</li> <li>UJT triggering of an SCR.</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> The common application of UJT is to trigger the some devices such as the SCR. In the UJT, the single p-n junction accounts for the terminology uni- junction. It was originally called a duo base diode due to the presence of two base contacts.	<u>5 min</u>
4	Question /Answer Q.WHAT IS VALLEY POINT? Ans. the voltage is min and any further increase in the current will place the device in the saturation Q. What is the power dissipation the UJT? Ans. it is 300mw	<u>5 min</u>

Assignment to be given:-

- 2 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 3 Electronic Devices And Ckt Theory: Boylested & Nashelsky; Pearson

# Lecture Plan -17

Semester:-IIIrd Class:-EEE Course

Course Code: EE-201-F

#### Subject: ELECTRONIC DEVICES & CIRCUITS Section-C

S. No.	Topic :- WORKING AND CHARACTERISTICS OF JFET.	Time Allotted:-
1.	<b>Introduction</b> Field effect transistor amplifiers provide an excellent voltage gain with the added feature of a high input resistance. They are also considered low power consumption with good frequency range.Fet is a voltage controlled device	<u>10 min</u>
2	<ul> <li>Division of the Topic</li> <li>Introduction to the JFET</li> <li>Characteristics of JFET</li> <li>Field bias configuration</li> <li>Self bias configuration</li> <li>Voltage divider configuration</li> <li>Source follower configuration</li> <li>Common gate configuration.</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> The JFET can be used as a linear amplifier or as a digital device in logic circuits. it is use widely n buffering applications and the output impedance f a jfet is same as that of a conventional BJT.	<u>5 min</u>
4	Question /Answer Q. What is the practical value of input resistance in jfet? Ans. $10^9 \Omega$ Q. Is the practical value of output resistance of jfet is different from that of BJT? Ans. NO they are practically same.	<u>5 min</u>

#### Assignment to be given:-

- 2 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 3 Electronic Devices And Ckt Theory: Boylested & Nashelsky; Pearson

# Lecture Plan -18

Semester:-IIIrd Class:-EEE

Course Code: EE-201-F

#### Subject: ELECTRONIC DEVICES & CIRCUITS Section-C

S. No.	<b>Topic :- CONSTRUCTION AND WORKING OF MOSFET</b>	Time Allotted:-
1.	<b>Introduction</b> The label mosfet stands for the metal –oxide-semiconductor-field-effect-transistor. There are two types of mosfet. Depletion type and the enhancement type mosfet. These are different in the characteristics and the operations.	<u>10 min</u>
2	<ul> <li>Division of the Topic</li> <li>Introduction to MOSFET</li> <li>Basic construction and the operation of the DEPLETION TYPE MOSFETS.</li> <li>Basic construction and the operation of the ENHANCEMENT TYPE MOSFETS.</li> <li>First two topics are covered in this lecture</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> Although there are some similarities in construction and mode of operation between the depletion type and the enhancement type MOSFETThe characteristics of the enhancement type mosfet are quite different from the depletion type MOSFET.	<u>5 min</u>
4	<ul> <li>Question /Answer</li> <li>Q.What is the purpose of the SiO<sub>2</sub> in depletion type mosfets?</li> <li>Ansit sets up an opposing electric field within the dielectric when exposed to the externally applied field.</li> <li>Q. What is the main cause of the high input impedance in the depletion type mosfet?</li> <li>Ans.SiO<sub>2</sub>.</li> </ul>	<u>5 min</u>

Assignment to be given:-

- 2 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 3 Electronic Devices And Ckt Theory: Boylested & Nashelsky; Pearson

# Lecture Plan -19

Semester:-IIIrd Class:-EEE

Course Code: EE-201-F

#### Subject: ELECTRONIC DEVICES & CIRCUITS Section-C

S. No.	Topic :- CONSTRUCTION AND WORKING OF MOSFET (CONTINUED)	Time Allotted:-
1.	<b>Introduction</b> The label mosfet stands for the metal –oxide-semiconductor-field-effect-transistor. There are two types of mosfet. Depletion type and the enhancement type mosfet. These are different in the characteristics and the operations.	<u>10 min</u>
2	Division of the Topic	
	<ul> <li>Basic construction and the operation of the ENHANCEMENT TYPE MOSFETS.</li> <li>N- channel &amp; p-channel EMOSFET</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> Although there are some similarities in construction and mode of operation between the depletion type and the enhancement type MOSFETThe characteristics of the enhancement type mosfet are quite different from the depletion type MOSFET.	<u>5 min</u>
4	Question /Answer Q.What is the purpose of the SiO <sub>2</sub> in depletion type mosfets? Ansit sets up an opposing electric field within the dielectric when exposed to the externally applied field. Q. What is the main cause of the high input impedance in the depletion type mosfet? Ans.SiO <sub>2</sub> .	<u>5 min</u>

Assignment to be given:-

- 4 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 3 Electronic Devices And Ckt Theory: Boylested & Nashelsky; Pearson

# Lecture Plan -20

<u>Semester:-IIIrd</u> <u>Class:-EEE</u> <u>Course C</u>

Course Code: EE-201-F

 Subject:
 ELECTRONIC DEVICES & CIRCUITS
 Section-C

S. No	Topic :- CHARACTERISTICS OF MOSFET	Time Allotted:-
1	Introduction	<u>10 min</u>
	SCHOTTKY equation will continue to be applicable for depletion type mosfet characteristics in both the depletion and the enhancement type regions. In both the regions it is necessary that the proper sign is to be included with $V_{GS}$ in the equation and the sign be carefully monitored in the mathematical operations.	
2.	<ul> <li>Division of the Topic</li> <li>➢ Characteristics of depletion type MOSFET: depletion mode</li> <li>● Enhancement mode</li> <li>➢ Characteristics of the enhancement type MOSFET:DRAIN CHARATERISTICS TRANSFER CHARACTERISTICS</li> </ul>	<u>30 min</u>
3	<b>Conclusion</b> The region of the positive gate voltage s on the drain or the transfer characteristics is often referred as the enhancement region , with the region between the cut-off and the saturation level of $I_{DSS}$ referred to as the depletion region.	<u>5 min</u>
4	Question /Answer Q.Which three pins are present in the depletion type mosfet? Ans. Gate, drain and source. Q. How many pins are present in the enhancement type mosfet / Ans. Four pins	<u>5 min</u>

#### Assignment to be given:-

Reference Readings:-

- 1 Solid State Electronic Devices: Streetman & Banerjee;Pearson
- 2 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 3 Electronic Devices And Ckt Theory: Boylested & Nashelsky; Pearson

# Lecture Plan-21

Semester:-IIIrd Class:-EEE Course Code:EE-201-F

#### Subject:-ELECTRONIC DEVICES & CIRCUITS Section-D

S. No.	Topic :- THYRISTOR	Time Allotted:-
1.	<b>Introduction</b> The thyristor has the characteristics similar to the thyratron tube. But from the construction view point, a thyristor (a pnpn device) belongs to transistor (pnp or npn device) family. The name thyristor is derived from the combination of the capital letters from the THYRatron and transistor. This means that the thyristor is a solid state device like a transistor and has the characteristics similar to that of a thyratron tube.	<u>10 min</u>
2	<ul> <li>Division of the Topic</li> <li>➢ Introduction to the thyristor</li> <li>➢ Terminal characteristics of thyristor</li> <li>➢ Static V-I characteristics of thyristors</li> <li>➢ Switching characteristics of thyristor</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> Thyristor is a four layers, three junction, p-n-p-n semiconductor switching device. It has three terminals anode, cathode and gate. For engineering applications of the thyristor, their terminal characteristics should be known. For economical and the reliable design of convector equipments the static and the switching characteristics of the thyristor are very important.	<u>5 min</u>
4	Question /Answer Q.How many p-n junctions are present in the thyristor? Ans.3 Q. When anode is positive with respect to the cathode in an SCR, the number of blocked p-n junctions is ? Ans. 1	<u>5 min</u>

Assignment to be given:-

- 2 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 3 Electronic Devices And Ckt Theory: Boylested & Nashelsky; Pearson

# Lecture Plan -22

Semester:-IIIrd Class:-EEE

Course Code: EE-201-F

#### Subject:-ELECTRONIC DEVICES & CIRCUITS Section-D

S. No.	Topic :- DIAC	Time Allotted:-
1.	<b>Introduction</b> The DIAC is an important member of thyristor family and usually employed for triggering TRIAC. A DIAC is a two-electrode bi-directional avalanche diode which can be switched from off-state to the on-state for either polarity of the applied voltage. Its equivalent ckt is a pair of inverted four layer diodes.	<u>10 min</u>
2	<ul> <li>Division of the Topic</li> <li>Introduction to diac</li> <li>Construction of diac</li> <li>Operation of diac</li> <li>V-I characteristics of diac</li> <li>Applications of diac</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> The diacs because of their symmetrical bidirectional switching characteristics are widely used as the triggering devices in the triac phase control ckt employed for lamp dimmer, heat control, universal motor speed control.	<u>5 min</u>
4	<ul> <li>Question /Answer</li> <li>Q.To which family the diac belongs?</li> <li>Ans. Thyristor family.</li> <li>Q. What is diac?</li> <li>Ans. A diac is a p-n-p-n structured four-layer, two terminal semiconductor device .</li> <li>diode has been derived from the diode that can work on AC.</li> </ul>	<u>5 min</u>

Assignment to be given:-

Reference Readings:- 1 Solid State Electronic Devices: Streetman & Banerjee; Pearson

2 Electronic Devices And Circuits: Milliman's & Halkins; MGH

3 Electronic Devices And Ckt Theory: Boylested & Nashelsky; Pearson

Semester:-IIIrd Class:-EEE

Course Code: EE-201-F

#### Subject: ELECTRONIC DEVICES & CIRCUITS Section-D

S. No.	Topic :-TRIAC	Time Allotted:-
1.	<b>Introduction</b> TRIAC is an abbreviation for three terminal ac switches. "TRI" indicates that the device has three terminals and "AC" indicates that the device controls ac current or can conduct in either direction. Due to its bidirectional conduction property the triac is used in the field of power electronics for control purposes.	<u>10 min</u>
2	<ul> <li>Division of the Topic</li> <li>Introduction to triac</li> <li>Constructional details of triac</li> <li>Operation of triac</li> <li>Characteristics of triac</li> <li>Applications of triac</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> Next to SCR, the triac is the most widely used member of the thyristor family. in fact, in many of control applications it has replaced SCR by virtue of the bidirectional conductivity. Motor speed regulation, temperature control, illumination control, liquid level control, phase control ckt , power switches are some of its main applications.	<u>5 min</u>
4	Question /Answer Q. what is triac? Ans. The triac is a three terminal, four layer, bidirectional semiconductor device. It incorporates two SCRs connected in inverse parallel with a common gate terminal in a single chip. Q. How many triggering modes are present in the V-I characteristics of triac? Ans. four	<u>5 min</u>
	incorporates two SCRs connected in inverse parallel with a common gate terminal in a single chip. Q. How many triggering modes are present in the V-I characteristics of triac? Ans. four	

Assignment to be given:-

- 2 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 3 Electronic Devices And Ckt Theory: Boylested & Nashelsky; Pearson

Semester:-IIIrd Class:-EEE Course Code:EE-201-F

#### Subject:-ELECTRONIC DEVICES & CIRCUITS Section-D

S. No.	Topic :- semiconductor lasers, light emitting materials.	Time Allotted:-
1.	Introduction The increasing use of the digital display in calculators, watches, and all form of instrumentation has contributed to the current extensive interest in structures that will emit light when properly biased. Solar cells are very frequently used these days. They convert the solar energy into electrical energy The energy transmitted at discrete packages called photons and it is directly proportional to the frequency	<u>10 min</u>
2	<ul> <li>Division of the Topic</li> <li>&gt; semiconductor lasers,</li> <li>&gt; light emitting materials.</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> The two types in common use today to perform this function are the light emitting diode (LED) and the liquid crystal display. Photo diode detectors are used in the alarm system and in the counter operation. Solar cells are becoming very popular as an alternative source of energy but still some new developments are required to maximize the conversion efficiency of the solar cells. The series arrangement of solar cells permits a voltage beyond that of a single element.	<u>5 min</u>
4	<ul><li>Question /Answer</li><li>Q.what is electroluminescence?</li><li>Ans.the process of giving off light by applying an electrical source of energy.</li><li>Q. what is efficacy?</li><li>Ans. it is a measure of the ability of the device to produce a desired effect.</li></ul>	<u>5 min</u>

Assignment to be given:-

- 2 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 3 Electronic Devices And Ckt Theory: Boylested & Nashelsky; Pearson

# Lecture Plan -25

Semester:-IIIrdClass:-EEECourse Code:EE-201-F

#### Subject:-ELECTRONIC DEVICES & CIRCUITS Section-D

S. No.	Topic :- Tunnel Diode: degenerate semiconductors	Time Allotted:-
1.	<b>Introduction</b> A <b>tunnel diode</b> or <b>Esaki diode</b> is a type of semiconductor diode that is capable of very fast operation, well into the microwave frequency region, by using the quantum mechanical effect called tunneling.	<u>10 min</u>
2	<ul> <li>Division of the Topic</li> <li>Introduction to Tunnel Diode</li> <li>Structure of Tunnel Diode</li> <li>Device operation and characteristics</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> Tunnel diodes are also relatively resistant to nuclear radiation, as compared to other diodes. This makes them well suited to higher radiation environments, such as those found in space applications.	<u>5 min</u>
4	Question /Answer Q.How Tunnel Diodes Function? Ans. Just like other general diodes, a tunnel diode consists of a pn junction. But the depletion layer in it is extremely narrow. Even the fastest of silicon diode is no match against these diodes.	<u>5 min</u>

Assignment to be given:-

- 2 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 3 Electronic Devices And Ckt Theory: Boylested & Nashelsky; Pearson

# Lecture Plan -26

Semester:-IIIrd Class:-EEE

Course Code: EE-201-F

#### Subject:-ELECTRONIC DEVICES & CIRCUITS Section-D

S. No.	Topic :- IMPATT diode	Time Allotted:-
1.	<b>Introduction</b> An <b>IMPATT diode</b> ( <b>IMP</b> act ionization <b>A</b> valanche Transit-Time) is a form of high- power diode used in high-frequency electronics andmicrowave devices. They operate at frequencies between about 3 and 100 GHz or more. A main advantage is their high-power capability. These diodes are used in a variety of applications from low- power radar systems to alarms.	<u>10 min</u>
2	<ul> <li>Division of the Topic</li> <li>➢ Introduction to IMPATT diode</li> <li>➢ IMPATT diode construction</li> <li>➢ Characteristics of IMPATT diode</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> If a free electron with sufficient energy strikes a silicon atom, it can break the covalent bond of silicon and liberate an electron from the covalent bond. If the electron liberated gains energy by being in an electric field and liberates other electrons from other covalent bonds then this process can cascade very quickly into a chain reaction producing a large number of electrons and a large current flow. This phenomenon is called impact avalanche.	<u>5 min</u>
4	Question /Answer Q.What is IMPATT? Ans. An IMPATT diode (IMPact ionization Avalanche Transit-Time) is a form of high-power diode used in high-frequency electronics andmicrowave devices.	<u>5 min</u>

Assignment to be given:-

- 2 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 3 Electronic Devices And Ckt Theory: Boylested & Nashelsky; Pearson

# Lecture Plan -27

Semester:-IIIrd Class:-EEE Course Co

Course Code: EE-201-F

#### Subject:-ELECTRONIC DEVICES & CIRCUITS Section-D

S. No.	Topic : Gunn diode	Time Allotted:-
1.	<b>Introduction</b> A <b>Gunn diode</b> , also known as a <b>transferred electron device</b> (TED), is a form of diode, asemiconductor electronic component, used in high-frequency electronics. Its internal construction is unlike other diodes in that it consists only of N- doped semiconductormaterial, whereas most diodes consist of both P and N-doped regions.	<u>10 min</u>
2	<ul> <li>Division of the Topic</li> <li>➢ Introduction Gunn diode</li> <li>➢ Operation of Gunn diode</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> Because of their high frequency capability, Gunn diodes are mainly used at microwave frequencies and above. They can produce some of the highest output power of any semiconductor devices at these frequencies. Their most common use is in oscillators, but they are also used in microwave amplifiers to amplify signals.	<u>5 min</u>
4	Question /Answer Q.What is another name of Gunn diode? Ans. A Gunn diode, also known as a transferred electron device (TED).	<u>5 min</u>

#### Assignment to be given:-

- 2 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 3 Electronic Devices And Ckt Theory: Boylested & Nashelsky; Pearson

# Lecture Plan -28

Semester:-IIIrd Class:-EEE Course Code:EE-201-F

#### Subject:-ELECTRONIC DEVICES & CIRCUITS Section-D

S. No.	Topic :- P-N-P-N diode	Time Allotted:-
1.	<b>Introduction</b> The <b>Shockley diode</b> (named after physicist William Shockley) is a four layersemiconductor diode which was one of the first semiconductor devices invented. It was a "pnpn" diode. It is equivalent to a thyristor with a disconnected gate.	<u>10 min</u>
2	Division of the Topic	
	<ul> <li>Introduction to PNPN Diode</li> <li>Operation of PNPN Diode</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> Small signal Shockley diodes are no longer manufactured, but the unidirectional thyristor breakover diode, also known as the <b>dynistor</b> , is a functionally equivalent power device.	<u>5 min</u>
4	Question /Answer Q.What is another name of PNPN DIODE? Ans. Shockley diode	<u>5 min</u>

Assignment to be given:-

# Lecture Plan -29

Semester:-IIIrd Class:-EEE Course Code:EE-201-F

Subject:-ELECTRONIC DEVICES & CIRCUITS Section-D

S. No.	Topic :-SCR	Time Allotted:-
1.	<b>Introduction</b> The SCR has the characteristics similar to the thyratron tube. But from the construction view point, a thyristor (a pnpn device) belongs to transistor (pnp or npn device) family. The name thyristor is derived from the combination of the capital letters from the THYRatron and transistor. This means that the thyristor is a solid state device like a transistor and has the characteristics similar to that of a thyratron tube.	<u>10 min</u>
2	<ul> <li>Division of the Topic</li> <li>Introduction to the SCR</li> <li>Terminal characteristics of SCR</li> <li>Static V-I characteristics of SCR</li> <li>Switching characteristics of SCR</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> Thyristor is a four layers, three junction, p-n-p-n semiconductor switching device. It has three terminals anode, cathode and gate. For engineering applications of the thyristor, their terminal characteristics should be known. For economical and the reliable design of convector equipments the static and the switching characteristics of the thyristor are very important.	<u>5 min</u>
4	Question /Answer Q.How many p-n junctions are present in the thyristor? Ans.3 Q. When anode is positive with respect to the cathode in an SCR , the number of blocked p-n junctions is ? Ans. 1	<u>5 min</u>

Assignment to be given:-

- 2 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 3 Electronic Devices And Ckt Theory: Boylested & Nashelsky; Pearson

# Lecture Plan -30

Semester:-IIIrd Class:-EEE Course Code:EE-201-F

 Subject:-ELECTRONIC DEVICES & CIRCUITS
 Section-D

S. No.	Topic :- IGBT	Time Allotted:-
1.	<b>Introduction</b> The <b>insulated-gate bipolar transistor</b> or <b>IGBT</b> is a three-terminal power semiconductor device primarily used as an electronic switch and in newer devices is noted for combining high efficiency and fast switching.	<u>10 min</u>
2	<ul> <li>Division of the Topic</li> <li>➢ Introduction to the IGBT</li> <li>➢ Terminal characteristics of IGBT</li> <li>➢ Static V-I characteristics of IGBT</li> </ul>	<u>30 min</u>
3.	<b>Conclusion</b> An IGBT has a significantly lower forward voltage drop compared to a conventional MOSFET in higher blocking voltage rated devices. As the blocking voltage rating of both MOSFET and IGBT devices increases, the depth of the n- drift region must increase and the doping must decrease, resulting in roughly square relationship decrease in forward conduction vs. blocking voltage capability of the device.	<u>5 min</u>
4	Question /Answer Q.What is full form of IGBT? Ans. Insulated-gate bipolar transistor.	<u>5 min</u>

Assignment to be given:-

- 2 Electronic Devices And Circuits: Milliman's & Halkins; MGH
- 3 Electronic Devices And Ckt Theory: Boylested & Nashelsky; Pearson