
#### **Communication Overview**




#### A Communications Model

- Source
  - generates data to be transmitted
- Transmitter
  - Converts data into transmittable signals
- Transmission System
  - Carries data
- Receiver
  - Converts received signal into data
- Destination
  - Takes incoming data

## Simplified Communications Model - Diagram




(a) General block diagram



(b) Example

## Simplified Data Communications Model



## Introduction to Digital & Analog Communication

## \*Overview

- Communication systems
- Analog Modulation
  - AM
  - FM
- Digital Modulation
  - ASK
  - FSK




## Remember the components of a communications system:


- Input transducer: The device that converts a physical signal from source to an electrical, mechanical or electromagnetic signal more suitable for communicating
- <u>Transmitter:</u> The device that sends the transduced signal
- Transmission channel: The physical medium on which the signal is carried
- Receiver: The device that recovers the transmitted signal from the channel
- Output transducer: The device that converts the received signal back into a useful quantity

### Analog Modulation

- The purpose of a communication system is to transmit information signals (baseband signals) through a communication channel
- The term baseband is used to designate the band of frequencies representing the original signal as delivered by the input transducer
  - For example, the voice signal from a microphone is a baseband signal, and contains frequencies in the range of 0-3000 Hz
  - The "hello" wave is a baseband signal:



#### Basic analog communications system



- The transmitter block in any communications system contains the modulator device
- The receiver block in any communications system contains the demodulator device
- The modulator modulates a carrier wave (the electromagnetic wave) which has a frequency that is selected from an appropriate band in the radio spectrum
- The demodulator extracts the original baseband signal from the received modulated signal



#### **To Summarize:**


Modulation is the process of impressing a low-frequency information signal (baseband signal )onto a higher frequency carrier signal

Modulation is done to bring information signals up to the Radio Frequency (or higher) signal


#### Types of Analog Modulation

- Amplitude Modulation (AM)
  - Amplitude modulation is the process of varying the amplitude of a carrier wave in proportion to the amplitude of a baseband signal. The frequency of the carrier remains constant
- Frequency Modulation (FM)
  - Frequency modulation is the process of varying the frequency of a carrier wave in proportion to the amplitude of a baseband signal. The amplitude of the carrier remains constant
- Phase Modulation (PM)
  - Another form of analog modulation technique

# Amplitude Modulation Carrier wave



#### Frequency Modulation



#### AM vs. FM

- AM requires a simple circuit, and is very easy to generate.
- It is simple to tune, and is used in almost all short wave broadcasting.
- The area of coverage of AM is greater than FM (longer wavelengths (lower frequencies) are utilized-remember property of HF waves?)
- However, it is quite inefficient, and is susceptible to static and other forms of electrical noise.




- ☐ The main advantage of FM is its audio quality and immunity to noise. Most forms of static and electrical noise are naturally AM, and an FM receiver will not respond to AM signals.
- ☐ The audio quality of a FM signal increases as the frequency deviation increases (deviation from the center frequency), which is why FM broadcast stations use such large deviation.
- ☐ The main disadvantage of FM is the larger bandwidth it requires


#### Digital Modulation

- The previous section presented analog communication systems that transmit information in analog form using Amplitude or Frequency modulation
- Digital communication systems also employ modulation techniques, some of which include:
  - Amplitude Shift Keying
  - Frequency Shift Keying
  - Phase Shift Keying


Basic digital communications system



## Amplitude Shift Keying




#### Frequency Shift Keying



#### Phase shift keying







- Modems are devices used to enable the transfer of data over the public switched telephone network (PSTN)
- The name modem comes from the name Modulator- DEModulator which describes the function the modem performs to transfer digital information over an analog network
- The goal is to produce a signal that can be transmitted easily and decoded to reproduce the original digital data. Primarily used to communicate via telephone lines, modems can be used over any means of transmitting analog signals

#### There are many kinds of modems available today:

#### **Internal modem:**

A modem card in your computer that is integrated within the system

Less expensive than external modems

Disadvantage is that you need to access inside the computer to replace the modem

#### **External modem**

A device that connects externally to your computer through a serial port

External power supply does not drain power from the computer Modem activity can easily be observed

More expensive than an internal modem



#### DSL (Digital Subscriber Line)

- A high-speed data service that works over conventional telephone lines and is typically offered by telephone companies
- It does not occupy the phone line-you can still talk on the phone
- Speed is much higher than regular modem

#### Cable modem

- A device that connects to the existing cable feed and to an Ethernet network card in the PC (also called a NIC for Network Interface Card)
- Is different than a common dial up modem
- Supports higher speeds
- Typically offered by cable companies
- Modems are the most popular means of Internet access, UCLA 2001 study of American Internet users shows that 81.3% of them use telephone modem, and 11.5% cable modem