


# WELDING PROCESSES

---


1. Arc Welding
2. Resistance Welding
3. Oxyfuel Gas Welding
4. Other Fusion Welding Processes
5. Solid State Welding
6. Weld Quality
7. Weldability
8. Design Considerations in Welding



## Two Categories of Welding Processes

---

- Fusion welding - coalescence is accomplished by melting the two parts to be joined, in some cases adding filler metal to the joint
  - Examples: arc welding, resistance spot welding, oxyfuel gas welding
- Solid state welding - heat and/or pressure are used to achieve coalescence, but no melting of base metals occurs and no filler metal is added
  - Examples: forge welding, diffusion welding, friction welding




## Arc Welding (AW)

---

A fusion welding process in which coalescence of the metals is achieved by the heat from an electric arc between an electrode and the work

- Electric energy from the arc produces temperatures ~ 10,000 F (5500 C), hot enough to melt any metal
- Most AW processes add filler metal to increase volume and strength of weld joint




## What is an Electric Arc?

---


An electric arc is a discharge of electric current across a gap in a circuit


- It is sustained by an ionized column of gas (*plasma*) through which the current flows
- To initiate the arc in AW, electrode is brought into contact with work and then quickly separated from it by a short distance



# Arc Welding

- A pool of molten metal is formed near electrode tip, and as electrode is moved along joint, molten weld pool solidifies in its wake






# Manual Arc Welding and Arc Time

---


- Problems with manual welding:
  - Weld joint quality
  - Productivity
- Arc Time = (time arc is on) divided by (hours worked)
  - Also called “arc-on time”
  - Manual welding arc time = 20%
  - Machine welding arc time ~ 50%



## Two Basic Types of AW Electrodes

---

- Consumable – consumed during welding process
  - Source of filler metal in arc welding
- Nonconsumable – not consumed during welding process
  - Filler metal must be added separately if it is added




## Consumable Electrodes

---

- Forms of consumable electrodes
  - Welding rods (a.k.a. sticks) are 9 to 18 inches and 3/8 inch or less in diameter and must be changed frequently
  - Weld wire can be continuously fed from spools with long lengths of wire, avoiding frequent interruptions
- In both rod and wire forms, electrode is consumed by the arc and added to weld joint as filler metal






## Nonconsumable Electrodes

---


- Made of tungsten which resists melting
- Gradually depleted during welding (vaporization is principal mechanism)
- Any filler metal must be supplied by a separate wire fed into weld pool



## Arc Shielding

---


- At high temperatures in AW, metals are chemically reactive to oxygen, nitrogen, and hydrogen in air
  - Mechanical properties of joint can be degraded by these reactions
  - To protect operation, arc must be shielded from surrounding air in AW processes
- Arc shielding is accomplished by:
  - Shielding gases, e.g., argon, helium,  $\text{CO}_2$
  - Flux



## Flux

A substance that prevents formation of oxides and other contaminants in welding, or dissolves them and facilitates removal


- Provides protective atmosphere for welding
- Stabilizes arc
- Reduces spattering



## Various Flux Application Methods

---


- Pouring granular flux onto welding operation
- Stick electrode coated with flux material that melts during welding to cover operation
- Tubular electrodes in which flux is contained in the core and released as electrode is consumed



## Power Source in Arc Welding

---


- Direct current (DC) vs. Alternating current (AC)
  - AC machines less expensive to purchase and operate, but generally restricted to ferrous metals
  - DC equipment can be used on all metals and is generally noted for better arc control



# Consumable Electrode AW Processes

---

- Shielded Metal Arc Welding
- Gas Metal Arc Welding
- Flux-Cored Arc Welding
- Electrode Gas Welding
- Submerged Arc Welding




## Shielded Metal Arc Welding (SMAW)


---

Uses a consumable electrode consisting of a filler metal rod coated with chemicals that provide flux and shielding


- Sometimes called "stick welding"
- Power supply, connecting cables, and electrode holder available for a few thousand dollars



# Shielded Metal Arc Welding (SMAW)








## Welding Stick in SMAW


---


- Composition of filler metal usually close to base metal
- Coating: powdered cellulose mixed with oxides and carbonates, and held together by a silicate binder
- Welding stick is clamped in electrode holder connected to power source
- Disadvantages of stick welding:
  - Sticks must be periodically changed
  - High current levels may melt coating prematurely



## Shielded Metal Arc Welding

- Shielded metal arc welding (stick welding) performed by a human welder (photo courtesy of Hobart Brothers Co.)






## SMAW Applications

---

- Used for steels, stainless steels, cast irons, and certain nonferrous alloys
- Not used or rarely used for aluminum and its alloys, copper alloys, and titanium




## Gas Metal Arc Welding (GMAW)


---


Uses a consumable bare metal wire as electrode with shielding by flooding arc with a gas

- Wire is fed continuously and automatically from a spool through the welding gun
- Shielding gases include argon and helium for aluminum welding, and CO<sub>2</sub> for steel welding
- Bare electrode wire plus shielding gases eliminate slag on weld bead
  - No need for manual grinding and cleaning of slag



# Gas Metal Arc Welding






## GMAW Advantages over SMAW

---

- Better arc time because of continuous wire electrode
  - Sticks must be periodically changed in SMAW
- Better use of electrode filler metal than SMAW
  - End of stick cannot be used in SMAW
- Higher deposition rates
- Eliminates problem of slag removal
- Can be readily automated




## Flux-Cored Arc Welding (FCAW)

---


Adaptation of shielded metal arc welding, to overcome limitations of stick electrodes - two versions

- Self-shielded FCAW - core includes compounds that produce shielding gases
- Gas-shielded FCAW - uses externally applied shielding gases
- Electrode is a continuous consumable tubing (in coils) containing flux and other ingredients (e.g., alloying elements) in its core




# Flux-Cored Arc Welding

Presence or absence of externally supplied shielding gas distinguishes: (1) self-shielded - core provides ingredients for shielding, (2) gas-shielded - uses external shielding gases








## Electrogas Welding (EGW)

---


Uses a continuous consumable electrode, flux-cored wire or bare wire with externally supplied shielding gases, and molding shoes to contain molten metal


- When flux-cored electrode wire is used and no external gases are supplied, then special case of self-shielded FCAW
- When a bare electrode wire used with shielding gases from external source, then special case of GMAW



# Electrogas Welding

- Electrogas welding using flux-cored electrode wire: (a) front view with molding shoe removed for clarity, and (b) side view showing molding shoes on both sides






## Submerged Arc Welding (SAW)


---


Uses a continuous, consumable bare wire electrode, with arc shielding by a cover of granular flux

- Electrode wire is fed automatically from a coil
- Flux introduced into joint slightly ahead of arc by gravity from a hopper
  - Completely submerges operation, preventing sparks, spatter, and radiation



# Submerged Arc Welding






# SAW Applications and Products

---


- Steel fabrication of structural shapes (e.g., I-beams)
- Seams for large diameter pipes, tanks, and pressure vessels
- Welded components for heavy machinery
- Most steels (except hi C steel)
- Not good for nonferrous metals



# Nonconsumable Electrode Processes

---

- Gas Tungsten Arc Welding
- Plasma Arc Welding
- Carbon Arc Welding
- Stud Welding




# Gas Tungsten Arc Welding (GTAW)


---

Uses a nonconsumable tungsten electrode and an inert gas for arc shielding


- Melting point of tungsten =  $3410^{\circ}\text{C}$  ( $6170^{\circ}\text{F}$ )
- A.k.a. Tungsten Inert Gas (TIG) welding
  - In Europe, called "WIG welding"
- Used with or without a filler metal
  - When filler metal used, it is added to weld pool from separate rod or wire
- Applications: aluminum and stainless steel mostly



# Gas Tungsten Arc Welding







# Advantages and Disadvantages of GTAW


---

## Advantages:

- High quality welds for suitable applications
- No spatter because no filler metal through arc
- Little or no post-weld cleaning because no flux

## Disadvantages:

- Generally slower and more costly than consumable electrode AW processes




## Plasma Arc Welding (PAW)


---


Special form of GTAW in which a constricted plasma arc is directed at weld area

- Tungsten electrode is contained in a nozzle that focuses a high velocity stream of inert gas (argon) into arc region to form a high velocity, intensely hot plasma arc stream
- Temperatures in PAW reach  $28,000^{\circ}\text{C}$  ( $50,000^{\circ}\text{F}$ ), due to constriction of arc, producing a plasma jet of small diameter and very high energy density



# Plasma Arc Welding





# Advantages and Disadvantages of PAW


---

## Advantages:

- Good arc stability and excellent weld quality
- Better penetration control than other AW processes
- High travel speeds
- Can be used to weld almost any metals

## Disadvantages:

- High equipment cost
- Larger torch size than other AW processes
  - Tends to restrict access in some joints



## Resistance Welding (RW)

---

- A group of fusion welding processes that use a combination of heat and pressure to accomplish coalescence
- Heat generated by electrical resistance to current flow at junction to be welded
  - Principal RW process is resistance spot welding (RSW)







Figure 31.12.



# Resistance Welding

- Resistance welding, showing components in spot welding, the main process in the RW group






## Components in Resistance Spot Welding

---

- Parts to be welded (usually sheet metal)
- Two opposing electrodes
- Means of applying pressure to squeeze parts between electrodes
- Power supply from which a controlled current can be applied for a specified time duration





# Advantages and Drawbacks of Resistance Welding


---

## Advantages:

- No filler metal required
- High production rates possible
- Lends itself to mechanization and automation
- Lower operator skill level than for arc welding
- Good repeatability and reliability

## Disadvantages:

- High initial equipment cost
- Limited to lap joints for most RW processes




## Resistance Spot Welding (RSW)

---



Resistance welding process in which fusion of faying surfaces of a lap joint is achieved at one location by opposing electrodes


- Used to join sheet metal parts
- Widely used in mass production of automobiles, metal furniture, appliances, and other sheet metal products
  - Typical car body has ~ 10,000 spot welds
  - Annual production of automobiles in the world is measured in tens of millions of units

# Spot Welding Cycle



- (a) Spot welding cycle
- (b) Plot of force and current
- Cycle: (1) parts inserted between electrodes, (2) electrodes close, (3) current on, (4) current off, (5) electrodes opened






## Resistance Seam Welding (RSEW)


---


Uses rotating wheel electrodes to produce a series of overlapping spot welds along lap joint

- Can produce air-tight joints
- Applications:
  - Gasoline tanks
  - Automobile mufflers
  - Various sheet metal containers



# Resistance Seam Welding






## Resistance Projection Welding (RPW)

---


A resistance welding process in which coalescence occurs at one or more small contact points on the parts


- Contact points determined by design of parts to be joined
  - May consist of projections, embossments, or localized intersections of parts



# Resistance Projection Welding

- (1) Start of operation, contact between parts is at projections; (2) when current is applied, weld nuggets similar to spot welding are formed at the projections






# Cross-Wire Welding



---






## Other Resistance Projection Welding Operations

- (a) Welding of fastener on sheetmetal and (b) cross-wire welding






## Oxyfuel Gas Welding (OFW)

---

Group of fusion welding operations that burn various fuels mixed with oxygen

- OFW employs several types of gases, which is the primary distinction among the members of this group
- Oxyfuel gas is also used in flame cutting torches to cut and separate metal plates and other parts
- Most important OFW process is oxyacetylene welding




## Oxyacetylene Welding (OAW)


---


Fusion welding performed by a high temperature flame from combustion of acetylene and oxygen

- Flame is directed by a welding torch
- Filler metal is sometimes added
  - Composition must be similar to base metal
  - Filler rod often coated with *flux* to clean surfaces and prevent oxidation



# Oxyacetylene Welding






## Acetylene (C<sub>2</sub>H<sub>2</sub>)


---


- Most popular fuel among OFW group because it is capable of higher temperatures than any other
  - Up to 3480°C (6300°F)
- Two stage reaction of acetylene and oxygen:
  - First stage reaction (inner cone of flame)
$$\text{C}_2\text{H}_2 + \text{O}_2 \rightarrow 2\text{CO} + \text{H}_2 + \text{heat}$$
  - Second stage reaction (outer envelope)
$$2\text{CO} + \text{H}_2 + 1.5\text{O}_2 \rightarrow 2\text{CO}_2 + \text{H}_2\text{O} + \text{heat}$$



# Oxyacetylene Torch

- Maximum temperature reached at tip of inner cone, while outer envelope spreads out and shields work surface from atmosphere
- Shown below is neutral flame of oxyacetylene torch indicating temperatures achieved






## Safety Issue in OAW

---

- Together, acetylene and oxygen are highly flammable
- $C_2H_2$  is colorless and odorless
  - It is therefore processed to have characteristic garlic odor




## OAW Safety Issue

---

- $C_2H_2$  is physically unstable at pressures much above 15 lb/in<sup>2</sup> (about 1 atm)
  - Storage cylinders are packed with porous filler material saturated with acetone ( $CH_3COCH_3$ )
  - Acetone dissolves about 25 times its own volume of acetylene
- Different screw threads are standard on  $C_2H_2$  and  $O_2$  cylinders and hoses to avoid accidental connection of wrong gases






## Alternative Gases for OFW

---

- Methylacetylene-Propadiene (MAPP)
- Hydrogen
- Propylene
- Propane
- Natural Gas




## Other Fusion Welding Processes

---

FW processes that cannot be classified as arc, resistance, or oxyfuel welding

- Use unique technologies to develop heat for melting
- Applications are typically unique
- Processes include:
  - Electron beam welding
  - Laser beam welding
  - Electroslag welding
  - Thermit welding




## Electron Beam Welding (EBW)

---

Fusion welding process in which heat for welding is provided by a highly-focused, high-intensity stream of electrons striking work surface


- Electron beam gun operates at:
  - High voltage (e.g., 10 to 150 kV typical) to accelerate electrons
  - Beam currents are low (measured in milliamps)
- Power in EBW not exceptional, but power density is



## EBW Vacuum Chamber

---


- When first developed, EBW had to be carried out in a vacuum chamber to minimize disruption of electron beam by air molecules
  - Serious inconvenience in production
    - Pumpdown time can take as long as an hour



## Three Vacuum Levels in EBW

---

1. High-vacuum welding – welding in same vacuum chamber as beam generation to produce highest quality weld
2. Medium-vacuum welding – welding in separate chamber but partial vacuum reduces pump-down time
3. Non-vacuum welding – welding done at or near atmospheric pressure, with work positioned close to electron beam generator - requires vacuum divider to separate work from beam generator



# EBW Advantages and Disadvantages of EBW


---

## Advantages:

- High-quality welds, deep and narrow profiles
- Limited heat affected zone, low thermal distortion
- No flux or shielding gases needed

## Disadvantages:

- High equipment cost
- Precise joint preparation & alignment required
- Vacuum chamber required
- Safety concern: EBW generates x-rays




## Laser Beam Welding (LBW)

---

Fusion welding process in which coalescence is achieved by energy of a highly concentrated, coherent light beam focused on joint

- LBW normally performed with shielding gases to prevent oxidation
- Filler metal not usually added
- High power density in small area
  - So LBW often used for small parts




## Comparison: LBW vs. EBW

---

- No vacuum chamber required for LBW
- No x-rays emitted in LBW
- Laser beams can be focused and directed by optical lenses and mirrors
- LBW not capable of the deep welds and high depth-to-width ratios of EBW
  - Maximum LBW depth = ~ 19 mm (3/4 in), whereas EBW depths = 50 mm (2 in)






## Thermit Welding (TW)


FW process in which heat for coalescence is produced by superheated molten metal from the chemical reaction of thermite


- *Thermite* = mixture of Al and  $\text{Fe}_3\text{O}_4$  fine powders that produce an exothermic reaction when ignited
- Also used for incendiary bombs
- Filler metal obtained from liquid metal
- Process used for joining, but has more in common with casting than welding



# Thermit Welding

- (1) Thermit ignited; (2) crucible tapped, superheated metal flows into mold; (3) metal solidifies to produce weld joint






## TW Applications

---


- Joining of railroad rails
- Repair of cracks in large steel castings and forgings
- Weld surface is often smooth enough that no finishing is required



## Solid State Welding (SSW)

---


- Coalescence of part surfaces is achieved by:
  - Pressure alone, or
  - Heat and pressure
    - If both heat and pressure are used, heat is not enough to melt work surfaces
  - For some SSW processes, time is also a factor
- No filler metal is added
- Each SSW process has its own way of creating a bond at the faying surfaces



## Success Factors in SSW

---


- Essential factors for a successful solid state weld are that the two faying surfaces must be:
  - Very clean
  - In very close physical contact with each other to permit atomic bonding



## SSW Advantages over FW Processes

---


- If no melting, then no heat affected zone, so metal around joint retains original properties
- Many SSW processes produce welded joints that bond the entire contact interface between two parts rather than at distinct spots or seams
- Some SSW processes can be used to bond dissimilar metals, without concerns about relative melting points, thermal expansions, and other problems that arise in FW



# Solid State Welding Processes

---

- Forge welding
- Cold welding
- Roll welding
- Hot pressure welding
- Diffusion welding
- Explosion welding
- Friction welding
- Ultrasonic welding




## Forge Welding

---

- Welding process in which components to be joined are heated to hot working temperature range and then forged together by hammering or similar means
- Historic significance in development of manufacturing technology
    - Process dates from about 1000 B.C., when blacksmiths learned to weld two pieces of metal
  - Of minor commercial importance today except for its variants






## Cold Welding (CW)

---

- SSW process done by applying high pressure between clean contacting surfaces at room temperature
- Cleaning usually done by degreasing and wire brushing immediately before joining
  - No heat is applied, but deformation raises work temperature
  - At least one of the metals, preferably both, must be very ductile
    - Soft aluminum and copper suited to CW
  - Applications: making electrical connections




## Roll Welding (ROW)


---


SSW process in which pressure sufficient to cause coalescence is applied by means of rolls, either with or without external heat

- Variation of either forge welding or cold welding, depending on whether heating of workparts is done prior to process
  - If no external heat, called *cold roll welding*
  - If heat is supplied, *hot roll welding*



# Roll Welding






## Roll Welding Applications

---

- Cladding stainless steel to mild or low alloy steel for corrosion resistance
- Bimetallic strips for measuring temperature
- "Sandwich" coins for U.S mint




## Diffusion Welding (DFW)

---

SSW process uses heat and pressure, usually in a controlled atmosphere, with sufficient time for diffusion and coalescence to occur


- Temperatures  $\leq 0.5 T_m$
- Plastic deformation at surfaces is minimal
- Primary coalescence mechanism is solid state diffusion
- Limitation: time required for diffusion can range from seconds to hours



## DFW Applications

---

- Joining of high-strength and refractory metals in aerospace and nuclear industries
- Can be used to join either similar and dissimilar metals
  - For joining dissimilar metals, a filler layer of different metal is often sandwiched between base metals to promote diffusion




## Explosion Welding (EXW)

---

SSW process in which rapid coalescence of two metallic surfaces is caused by the energy of a detonated explosive


- No filler metal used
- No external heat applied
- No diffusion occurs - time is too short
- Bonding is metallurgical, combined with mechanical interlocking that results from a rippled or wavy interface between the metals

# Explosive Welding





Commonly used to bond two dissimilar metals,  
in particular to clad one metal on top of a  
base metal over large areas






# Explosive Welding

- Commonly used to bond two dissimilar metals, e.g., to clad one metal on top of a base metal over large areas
- (1) Setup in parallel configuration, and (2) during detonation of the explosive charge






## Friction Welding (FRW)

---


SSW process in which coalescence is achieved by frictional heat combined with pressure


- When properly carried out, no melting occurs at faying surfaces
- No filler metal, flux, or shielding gases normally used
- Process yields a narrow HAZ
- Can be used to join dissimilar metals
- Widely used commercial process, amenable to automation and mass production



# Friction Welding

- (1) Rotating part, no contact; (2) parts brought into contact to generate friction heat; (3) rotation stopped and axial pressure applied; and (4) weld created





# Applications and Limitations of Friction Welding


---

## Applications:

- Shafts and tubular parts
- Industries: automotive, aircraft, farm equipment, petroleum and natural gas

## Limitations:

- At least one of the parts must be rotational
- Flash must usually be removed (extra operation)
- Upsetting reduces the part lengths (which must be taken into consideration in product design)




## Friction Stir Welding (FSW)

---


SSW process in which a rotating tool is fed along a joint line between two workpieces, generating friction heat and mechanically stirring the metal to form the weld seam


- Distinguished from FRW because heat is generated by a separate wear-resistant tool rather than the parts
- Applications: butt joints in large aluminum parts in aerospace, automotive, and shipbuilding



# Friction Stir Welding

- (1) Rotating tool just before entering work, and (2) partially completed weld seam






# Advantages and Disadvantages of Friction Stir Welding

---

- Advantages
  - Good mechanical properties of weld joint
  - Avoids toxic fumes, warping, and shielding issues
  - Little distortion or shrinkage
  - Good weld appearance
- Disadvantages
  - An exit hole is produced when tool is withdrawn
  - Heavy duty clamping of parts is required




## Ultrasonic Welding (USW)

---

Two components are held together, and oscillatory shear stresses of ultrasonic frequency are applied to interface to cause coalescence



- Oscillatory motion breaks down any surface films to allow intimate contact and strong metallurgical bonding between surfaces
- Temperatures are well below  $T_m$
- No filler metals, fluxes, or shielding gases
- Generally limited to lap joints on soft materials






# Ultrasonic Welding

- (a) General setup for a lap joint; and (b) close-up of weld area






## USW Applications

---

- Wire terminations and splicing in electrical and electronics industry
  - Eliminates need for soldering
- Assembly of aluminum sheet metal panels
- Welding of tubes to sheets in solar panels
- Assembly of small parts in automotive industry




# Weld Quality

---

Concerned with obtaining an acceptable weld joint that is strong and absent of defects


- Also concerned with the methods of inspecting and testing the joint to assure its quality
- Topics:
  - Residual stresses and distortion
  - Welding defects
  - Inspection and testing methods



# Residual Stresses and Distortion





---


- Rapid heating and cooling in localized regions during FW result in thermal expansion and contraction that cause residual stresses
- These stresses, in turn, cause distortion and warpage
- Situation in welding is complicated because:
  - Heating is very localized
  - Melting of base metals in these regions
  - Location of heating and melting is in motion (at least in AW)



# Residual Stresses and Distortion

- (a) Butt welding two plates
- (b) Shrinkage
- (c) Residual stress patterns
- (d) Likely warping of weldment






## Techniques to Minimize Warpage

---


- Welding fixtures to physically restrain parts
- Heat sinks to rapidly remove heat
- Tack welding at multiple points along joint to create a rigid structure prior to seam welding
- Selection of welding conditions (speed, amount of filler metal used, etc.) to reduce warpage
- Preheating base parts
- Stress relief heat treatment of welded assembly
- Proper design of weldment



# Welding Defects

---

- Cracks
- Cavities
- Solid inclusions
- Imperfect shape or unacceptable contour
- Incomplete fusion
- Miscellaneous defects




## Welding Cracks

---

Fracture-type interruptions either in weld or in base metal adjacent to weld


- Serious defect because it is a discontinuity in the metal that significantly reduces strength
- Caused by embrittlement or low ductility of weld and/or base metal combined with high restraint during contraction
- In general, this defect must be repaired






# Welding Cracks

- Various forms of welding cracks






# Cavities

---

Two defect types, similar to defects found in castings:

1. Porosity - small voids in weld metal formed by gases entrapped during solidification
  - Caused by inclusion of atmospheric gases, sulfur in weld metal, or surface contaminants
2. Shrinkage voids - cavities formed by shrinkage during solidification




## Solid Inclusions

---

Nonmetallic material entrapped in weld metal


- Most common form is slag inclusions generated during AW processes that use flux
  - Instead of floating to top of weld pool, globules of slag become encased during solidification
- Other forms: metallic oxides that form during welding of certain metals such as aluminum, which normally has a surface coating of  $\text{Al}_2\text{O}_3$




# Incomplete Fusion

A weld bead in which fusion has not occurred throughout entire cross section of joint


- Several forms of incomplete fusion are shown below






## Weld Profile in AW

- (a) Desired profile for single V-groove weld joint, (b) undercut - portion of base metal melted away, (c) underfill - depression in weld below adjacent base metal surface, and (d) overlap - weld metal spills beyond joint onto part surface but no fusion occurs






# Inspection and Testing Methods

---


- Visual inspection
- Nondestructive evaluation
- Destructive testing



# Visual Inspection

---

- Most widely used welding inspection method
- Human inspector visually examines for:
  - Conformance to dimensions, wWarpage
  - Cracks, cavities, incomplete fusion, and other surface defects
- Limitations:
  - Only surface defects are detectable
  - Welding inspector must also decide if additional tests are warranted




# Nondestructive Evaluation (NDE) Tests

---


- Ultrasonic testing - high frequency sound waves through specimen to detect cracks and inclusions
- Radiographic testing - x-rays or gamma radiation provide photograph of internal flaws
- Dye-penetrant and fluorescent-penetrant tests - to detect small cracks and cavities at part surface
- Magnetic particle testing – iron filings sprinkled on surface reveal subsurface defects by distorting magnetic field in part








## Destructive Testing


- Tests in which weld is destroyed either during testing or to prepare test specimen
- Mechanical tests - purpose is similar to conventional testing methods such as tensile tests, shear tests, etc
  - Metallurgical tests - preparation of metallurgical specimens (e.g., photomicrographs) of weldment to examine metallic structure, defects, extent and condition of heat affected zone, and similar phenomena



# Mechanical Tests in Welding

- (a) Tension-shear test, (b) fillet break test, (c) tension-shear of spot weld, and (d) peel test for spot weld






# Weldability

---

Capacity of a metal or combination of metals to be welded into a suitable structure, and for the resulting weld joint(s) to possess the required metallurgical properties to perform satisfactorily in intended service


- Good weldability characterized by:
  - Ease with which welding is accomplished
  - Absence of weld defects
  - Strength, ductility, and toughness in welded joint



## Weldability Factors – Welding Process

---


- Some metals or metal combinations can be readily welded by one process but are difficult to weld by others
  - Example: stainless steel readily welded by most AW and RW processes, but difficult to weld by OFW



## Weldability Factors – Base Metal

---


- Some metals melt too easily; e.g., aluminum
- Metals with high thermal conductivity transfer heat away from weld, which causes problems; e.g., copper
- High thermal expansion and contraction in metal causes distortion problems
- Dissimilar metals pose problems in welding when their physical and/or mechanical properties are substantially different



## Other Factors Affecting Weldability

---


- Filler metal
  - Must be compatible with base metal(s)
  - In general, elements mixed in liquid state that form a solid solution upon solidification do not cause a problem
- Surface conditions
  - Moisture can result in porosity in fusion zone
  - Oxides and other films on metal surfaces can prevent adequate contact and fusion



## Design Considerations in Welding

---

- Design for welding - product should be designed from the start as a welded assembly
  - Not as a casting or forging or other formed shape
- Minimum parts - welded assemblies should consist of fewest number of parts possible
  - Example: usually more cost efficient to perform simple bending operations on a part than to weld an assembly from flat plates and sheets




# Arc Welding Design Guidelines

---


- Good fit-up of parts - to maintain dimensional control and minimize distortion
  - Machining is sometimes required to achieve satisfactory fit-up
- Assembly must allow access for welding gun to reach welding area
- Design of assembly should allow flat welding to be performed as much as possible, since this is the fastest and most convenient welding position






# Arc Welding Positions


- Welding positions defined here for groove welds: (a) flat, (b) horizontal, (c) vertical, and (d) overhead




(a)




(b)



(c)



(d)



## Design Guidelines - RSW

---

- Low-carbon sheet steel up to 0.125 (3.2 mm) is ideal metal for RSW
- How additional strength and stiffness can be obtained in large flat sheet metal components
  - Spot welding reinforcing parts into them
  - Forming flanges and embossments
- Spot welded assembly must provide access for electrodes to reach welding area
- Sufficient overlap of sheet metal parts required for electrode tip to make proper contact